

COIL WINDING MACHINE ERN G-VERSION

USER'S GUIDE

Version: 3.3

Issue Date : 25.04.2016



ERN 22, 32, 32S, 42, 52



TPC s.r.o.
Pálenica 53/79
033 01 Liptovský Hrádok
SLOVAKIA
Tel.: +421-44-5221633
Fax: +421-44-5222088
E-mail: tpc@tpc.sk
www.tpc.sk

1. Introduction	1
1.1 Characteristic features	1
2. Technical data	2
2.1 Climatic conditions	2
3. Description of machine	2
3.1 Description of controls	3
4. Installation and preparation of working equipment	5
4.1 Connection to the power	5
5. Winding operation	6
5.1 Machine switching ON and gear setting	6
5.2 Winding data back up while electricity drop	7
5.3 Winding and view window	8
5.4 Explanation of conceptions STANDSTILL, START, STOP	8
5.5 Winding program selection	9
5.6 Start and Stop of winding cycle	10
5.7 Foot pedal	11
5.8 Protection shield	11
5.9 Winding corrections	12
5.9.1 Spindle reference position setting	12
5.9.2 Wire guide relative position setting	12
5.9.3 Number of turns correction	13
5.9.4 Total counter	14
5.9.5 Wire guide correction	15
5.9.6 Wire guide direction change	15
5.9.7 Abort step	16
5.9.8 Back winding	16
5.9.9 Deceleration ramp for the STOP - button	17
6. Programming	18
6.1 Basis of programming	19
6.2 Step choice	19
6.3 Step parameters programming	20
6.3.1 Basic step types	20
6.3.2 Choice of step type	20
6.3.3 Winding step	21
6.3.4 Wire guide shift	26
6.3.5 Wire guide jump	28
6.3.6 Delay	29
6.4 Display and assignment of the layer	31
6.5 Programming corrections	32
6.5.1 Insert an empty step	32
6.5.2 Delete step	33
6.5.3 Copy step	34
6.5.4 Global change	35
6.5.5 Coordinate offset	36
6.6 Special functions	37
6.6.1 Layer-stop	37
6.6.2 Automatic correction	38
6.6.3 Automatic switch to manual regime	40
6.6.4 Trapezoidal winding	41

6.7 Auxiliary inputs and outputs	43
6.7.1 View window for inputs and outputs	43
6.7.2 Digital inputs programming	44
6.7.3 Digital outputs programming	45
6.8 Program name	47
7. Program saving and opening	48
7.1 Program opening	49
7.2 Program saving	50
8. Menu	52
8.1 Program locking	54
8.2 USB flash drive	54
8.3 Machine model choice	54
8.4 Display language	55
8.5 Joystick action	55
8.6 Program (block) delete	56
8.7 Access PIN code setting	56
8.8 Error messages	57
8.9 Winding machine number	58
8.10 Accept file name	58
9. ERROR report	59
10. USB host port	60
10.1 Display help	62
10.2 Tree type structure	62
10.3 Load from flash drive	63
10.4 Save actual program to flash drive	65
10.5 Create a new directory	67
10.6 Delete file or directory	68
10.7 Rename file or directory	68
10.8 Save marked programs to flash drive	69
10.9 Save programs 1- 80 (81-160) to flash drive	71
10.10 Load all programs from flash drive	72
10.11 Firmware upgrades	73
11. Gear change	77
12. Serial interface RS 232	77
13. Package contents	78
14. Fuse change	78
15. Maintenance	78
16. Warranty period and service	78
17. Appendices	

1. INTRODUCTION

Bench-type universal coil winding machine ERN G is designed for winding coils, transformers, chokes, resistors etc. with wire up to - see technical data.

1.1 Characteristic features:

- wide range of application for winding simple or complicated coils, multichamber coils, trapezoidal or asymmetric windings
- AC servo, which is used as the spindle drive, assures excellent dynamical parameters, constant torque and accurate positioning
- wire guide on ball bearings with a separate stepping motor
- accurate reversible turn counting
- microprocessor-controlled winding cycle without time waste
- wide programming options
- memory for 160 complicated coils (up to 350 steps)
- viewable and easy reading graphical display
- special functions LAYER-STOP, AUTOMATIC CORRECTION, MANUAL REGIME
- 4 programmable digital outputs
- 4 programmable digital inputs
- communication with PC by optically isolated interface RS-232 and USB host port
- possibility for the creation of a wireless network by LAN or BLUETOOTH modules

2. TECHNICAL DATA

	ERN22	ERN32	ERN32S	ERN42	ERN52
Wire diameter (mm):	0,02 - 1,7	0,02 - 2,5	0,02 - 3,0	0,02 - 5,0	0,02 - 5,0
Pitch range (mm/rev):	0,008 - 40	0,008 - 40	0,008 - 40	0,008 - 40	0,008 - 40
Winding width (mm):	0,1 - 210	0,1 - 300	0,1 - 300	0,1 - 300	0,1 - 450
Winding speed / torque (rpm/Nm):	12000 / 0,7	6000 / 1,5	4000 / 3	4000 / 3,5	4000 / 3,5
	6000 / 1,5	1500 / 6	1000 / 12	1000 / 15	1000 / 15
	3000 / 3	750 / 12	500 / 24	500 / 30	500 / 30
Accuracy of spindle stop (rev):	0,01	0,01	0,01	0,01	0,01
Spindle position pre-set (rev):	0,01	0,01	0,01	0,01	0,01
Max.speed of wire guide - shift (mm/s)	100	100	100	100	100
- winding	75	75	75	75	75
Acceleration/deceleration:	table	table	table	table	table
Max.coil diameter (mm):	180	250	250	450	450
Distance between centres (mm):	250	340	340	330	650
Dimensions (mm):	780 x 420	870 x 460	870 x 460	910 x 530	1235 x 530
Weight (kg):	85	120	120	140	180
Power supply (V/Hz):	230 / 50-60	230 / 50-60	3x 400/50-60	3x 400/50-60	3x 400/50-60
Power consumption (kVA):	1	1,2	1,5	1,5	1,5
Noise (dB):	74	74	74	74	74

2.1 Climatic conditions


Machine is designed for normal workshop conditions with relative air moisture of 70% and temperature in the range from +15 up to +30°C.

3. DESCRIPTION OF MACHINE

Coil winding machine ERN consists of the following parts:



- controller containing control electronics and programming elements
- drive unit containing servomotor with gears, pitch control unit with stepping motor, power electronics and control elements
- base plate
- protection shield
- support with spool holders and dereelers (optional accessories)
- tailstock (optional accessories)
- wire guides (optional accessories)

Winding cycle (linear acceleration, max.speed, linear deceleration and stop) is running automatically after pressing the START-button. Deceleration is controlled by microprocessor to ensure accurate stopping and spindle positioning.



3.1 Description of controls

- 1 - POWER ON / OFF switch
- 2 - EMERGENCY STOP - disconnects power in emergency
- 3 - POWER ON indicator
- 4 - START button - starts winding cycle
- 5 - STOP button - interrupts winding cycle
- 6 - BRAKE ON / OFF - switches on/off the electromagnetic brake
- 7 - DISPLAY
- 8 - ENTER button - enters data to the memory
- 9 - PLUS and MINUS buttons - parameters correction and step choice
- 10 - RESET - sets the initial state
- 11 - Numeric buttons - enter the coil name as well
- 12 - Multifunction buttons - display served options choice
- 13 - Function buttons
- 14 - Connector for serial interface RS 232
- 15 - Gear cover with timing belt
- 16 - Connector for foot pedal
- 17 - Fixing screws
- 18 - Connectors for inputs and outputs
- 19 - Power plug
- 20 - AC circuit breaker
- 21 - USB host port



4. INSTALLATION AND PREPARATION OF WORKING EQUIPMENT

The machine operating is allowed only by skilled person who is acquainted with user's guide and safety formulas. The training is provided by producer or qualified person.

The machine is delivered partly disassembled for easier packing and transport. Before you switch the machine ON, for the first time, assemble it as follows:

- a) Mount the controller on the drive unit. Connect the power plug, the 25-pin connector and 9-pin connector for CAN- BUS on the back panel of the controller
- b) Check and fasten the fuse cartridges on the back panel of the drive unit
- c) Assemble support with spool holders and dereelers
- d) Connect the foot pedal to the connector (16)

Assembly is completed by this and prepared to work.

4.1 Connection to the power

The machine must be powered:

ERN 22,32 - N/PE230V, 50 Hz TN-S with tolerance $\pm 5\%$ and max. power consumption 1.2 kVA.

ERN 32S,42,52 - 3N/PE400V/230V, 50 Hz TN-S, tolerance $\pm 5\%$, max.power consumption 1.5 kVA.

Before plug in the connection cable make sure that electric power is in accordance with technical requirements. Only professional staff who are qualified in electrical engineering are allowed to install the power connection to the machine.

Since the leakage current to PE is more than 3,5 mA, in compliance with IEC 61800-5-1 the PE connection must be doubled.

USE THE PE TERMINAL ON THE MACHINE BACK SIDE FOR THIS PARALLER PE CONNECTION.


If a residual current protective device is used, we recommend that each winding machine be protected individually using a 30 mA RCD.

There is no guarantee for damages caused by wrong or out of range connection to the power supply.


5. WINDING OPERATION

5.1 Machine switching ON and gear setting

After switching ON (1) the introduction window shows,



which provides informations about, for what type of machine is controller set. In this window we can change the set gear, which must be in ABSOLUTE ACCORDANCE with the set of mechanical gear.



After pressing ENTER-button, the initial set is done, which means, that wire guide is shifted left home (zero position), zero number of turns, zero step and the last program is set.

5.2 Winding data back up while electricity drop

In this window, we can activate the initial setting of the machine (wire guide position, number of turns and step) for the back up values.




After the activation of this function (MEM.POS.ON) the initial setting will be actualized for the values, memorized while electricity drop.

FOR USING THIS FUNCTION, THE MACHINE MUST BE EQUIPPED WITH THE UNINTERRUPTIBLE POWER SUPPLY UNIT (UPS) AND THE REPORT OF ELECTRICITY DROP (relay for POWER) MUST BE INSTALLED. IF THE MACHINE IS NOT EQUIPPED BY THIS, THE ACTIVATION OF THIS FUNCTION DOES NOT INFLUENCE THE INITIAL SETTING, WHICH IS STILL SET ON ZERO VALUES.


5.3 Winding and view window

These are two basic windows, in which we can start programmed cycle. Repeated pressing of the ENTER-button caused the switching.

Winding window - provides actual information about winding process



View window - displays the view of programmed step parameters



Winding is possible only in these two windows. If any other window is opened, the cycle start is blocked.

5.4 Explanation of conceptions STANDSTILL, START, STOP


STANDSTILL: State after switching ON the machine and pressing ENTER, or after the step finishing. Start from this state shifts program one step forward, generally. E.g. when we are in the step 0, after starting, the step 1 is running.

START: Active run of some step type (winding, shift, jump and pause).

STOP: State after pressing the STOP-button (cycle interruption). Repeated start activates interrupted run and there is no step shifting.

5.5 Winding program selection

Winding program, we are just working with(we can perform winding or program creation) is called **ACTUAL PROGRAM**. Actual program is located in so-called working part of memory. Desired winding program can be loaded to the working part of memory either from internal memory of the Winder, USB flash drive or a PC equipped by software GRAPHIC.



Proceeding by program selection:

- internal memory - see section 7.1, page 49
- USB flash drive - see section 10.3, page 63
- PC - see GRAPHIC manual

5.6 Start and stop of winding cycle (program)

Winding cycle is actuated by pressing START-button (4), or foot pedal.

There is a possibility to start program from each step. Required step is set up by the buttons



, or numeric keyboard.

STOP-button (5) interrupts the winding cycle. It is the priority button, what means, that the cycle interruption at incorrect time (while deceleration), may cause inaccurate stopping and positioning of the spindle.

Cycle interruption at the step WINDING allows almost all corrections and adjustments. Repeated cycle start by START-button or foot pedal activates step, where the program interruption has been done.

Step types SHIFT, JUMP and PAUSE do not allow any corrections or adjustments during interruption.

5.7 Foot pedal

Winding machine may be equipped by following types of foot pedals:


Double foot pedal controls START, BRAKE RELEASE

- left pedal releases the spindle brake
- right pedal works as parallel START-button

Double foot pedal controls SPEED, BRAKE RELEASE



- left pedal releases the spindle brake
- right foot pedal controls spindle speed depending on pressing level

Maximal speed, acceleration and deceleration ramp may be set up by PEDAL button.



Speed set up like this, is valid for assigned program and it is independent on speed programmed, in single program steps. Explain as: max.speed (ordinary lower) set up by START pedal may be different, then max.speed set up by START-button.

If we require the same max.pedal speed as speed, programmed in single program step, we need to press multifunction button PROGRAM SPEED.



Accel. / Decel. ramp for pedal

CODE	Accel.time (sec.)	Decel. time (sec.)
1	1	0,5
2	2	1
3	3	1,5
4	4	2
5	6	3
6	8	4
7	10	5
8	12	6

Max. pedal speed is controlled by values, programmed in single program steps, in this case.

Acceleration and deceleration ramp values are always taken from window PEDAL SETUP.

Winding cycle start continuity

This option is utilized during winding start. Wire application and winding of the first turns is done by pedal and then by pressing START-button (4) cycle continues.

5.8 Protection shield

Protection shield may be programmed as:

CLOSED

There is a possibility of winding only if the protection shield is closed.
When the shield is opened, the cycle is interrupted.

OPENED

There is a possibility of winding if the protection shield is opened, but the spindle speed is limited for safety value, automatically.
When the shield is closed during the winding, the cycle continues with the speed value programmed previously.

5.9 WINDING CORRECTIONS

Program corrections and adjustments are allowed only in the state "STANDSTILL" or "Winding STOP". Keys are blocked in other states. When there is beep warning after the key pressing, the operation is illogical or inaccessible.

5.9.1 Spindle reference position setting

The spindle can be positioned in the range \pm a few degrees and exact position is kept for any amount of windings.

Reference (zero) spindle position is set up by follows:


- switch the brake-off by the switch (6)
- turn the spindle manually to the required position and return the switch (6) to the former position
- press RESET then ENTER


Note: When you switch the machine ON (by switch POWER or EMERGENCY STOP), RESET is running automatically and the spindle position is taken as reference position.

5.9.2. Wire guide relative position setting

This correction shifts zero coordinate of the wire guide (relative zero position). It allows you to correct the wire guide position to be in accordance with the bobbin or winding tool.

Default : 5 mm







Holding the buttons **-** **+** pressed (cca 0,5 s) moves the wire guide continuously.

5.9.3. Number of turns correction

We can change the number of turns counted actually.

Correction of decimal turn number e.g. XX.3 to XX.0 without adequate spindle turn, leads to the loss of reference position..






Multifunction RESET-button set to zero actual counter state.

5.9.4 Total counter


We can switch between TOTAL COUNTER and COUNTER. TOTAL COUNTER counts all spindle turns until it is set to zero by RESET, or is set differently by numeric keyboard.

Both counters are independent. By switching is only displayed one of it !



5.9.5. Wire guide correction


Correction allows you to correct the wire guide position while winding process.



Holding the buttons pressed (cca 0,5 s) moves the wire guide continuously.


5.9.6. Wire guide direction change

Correction allows you to change the direction of wire guide while winding.




5.9.7. Step abort

Correction allows you to abort actual running step.




Multifunction ABORT STEP button returns the STANDSTILL state.




5.9.8. Back winding

Correction allows you to wind back the required number of turns.




We can wind back required number of turns only by pedal. The number of turns is counted back and the wire guide moves in opposite direction.



Pressing of multifunction button "WINDING" ends back winding.

5.9.9. Deceleration ramp for the STOP-button

Deceleration ramp for the STOP button can be set. This ramp is whenever a bit faster (control by software) than programmed deceleration ramp.




CODE	TIME [s]
1	1,0
2	1,5
3	2,0
4	3,0
5	4,0
6	6,0
7	8,0
8	12,0


Presentated values are valid for max.speed.

6. PROGRAMMING


Entering the data:




Use the ENTER-button for execution entered value or for return from any function.

Programming is not possible in the step 00. By button  or numeric keyboard we need to choose any other step. When there is beep warning after the keep pressing, the operation is illogical or inaccessible.


Created program is saved to the working part of memory (program in this memories is designated as a ACTUAL PROGRAM). We can either overwrite (or modify) the already existing program, or open the new one.





6.1 Basis of programming

Winding program is logical sequence of a few(1-350) joined steps.



Joining to the next step is defined by the type of cycle.

If the type of cycle "END " is programmed to the specific step, it comes to this, that end of program and after pressing START- button, program is restarted and step 1 is running.


Max.step capacity for the one winding program is 350 !

6.2 Step choice

Only in the winding or viewable window we can choose the required step as follows:

a) directly by numeric keyboard

b) by buttons - or +



6.3 Step parameters programming

6.3.1 Basic step types

Every step can be programmed as WINDING, SHIFT, JUMP or PAUSE.


Winding - is defined by following parameters: number of turns, speed and spindle direction, pitch, left and right reversal point

Shift - spindle is not turning and the wire guide is shifting to the programmed coordinate


Jump - spindle is not turning and the wire guide is shifting from its position to the left or right, in accordance with the programmed value

Pause - spindle and wire guide are idle and the pause duration depends on programmed time

6.3.2 Choice of step type


By pressing the button  and then by pressing the multifunction buttons we can choose the desired step type. Concurrently, we can entry the main parameter of the chosen step type, what means:

- number of turns for winding
- coordinate value for shift
- lenght for jump
- time for pause




6.3.3 Winding step

Number of turns



If " 0 " is programmed to the number of turns, this winding step turns the spindle to the zero reference position. Direction of the spindle speed is taken from the previous winding step !


Spindle speed



Spindle acceleration and deceleration



Entry of values 1 to 8 for acceleration and deceleration according to the enclosed table.



CODE	ACCEL. (s)	DECCEL. (s)
1	1,5	1,5
2	2,3	2,3
3	3	3
4	4,5	4,5
5	6	6
6	9	9
7	12	12
8	16	16

Spindle direction and protection shield



Step : 2
Prog.: NEW

PROGRAMMING SPEED

Accel./Dec 23

2499

SPEED CLOSE

Range : 0 - 6000 [rpm]
Enter spindle speed !



Protection shield programming



Spindle direction programming

Pitch




Step : 2
Prog.: NEW

PROGRAMMING PITCH

0.000

Range : 0.008 - 40.000 [mm]
Enter pitch !



ENTER

Step : 2
Prog.: NEW

WINDING

LAYER

Turns : 1500.0

L.Rev : 0.0 R.Rev : 0.0

Speed : 2499 : Acc / Dec : 23

Pitch : 0.3

Cycle : Shield: CLOSE

Left reversal point




Step : 2
Prog.: NEW

PROGRAMMING LEFT REV. POINT


SHIFTING ON

0.0



Range : 0.0 - 300.0 [mm]
Enter left reversion point !




ENTER



Right reversal point




ENTER




Switching OFF the wire guide shifting during programming

We can switch OFF the wire guide shifting by multifunction button SHIFT ON / OFF during programming.



Type of cycle

Set the type of cycle and choose, how to continue to the next step.



END



End of program

By pressing START-button, program is restarted and step 1 is running.

STOP



Cycle stop

After step finish, program stops and the next step is activated by START-button.

ContSLOW



Continual cycle with deceleration



After step finish, program starts the next step automatically, without pressing the START-button. Winding step decelerates to zero, at first.

ContFAST




Continual cycle without deceleration

After step finish, program starts the next step automatically, without pressing the START-button. Spindle deceleration is canceled. Only winding steps can be joined by this cycle.



Number of turns cancel and the wire guide direction after start



Number of turns cancel.


CANCEL - previous counted number of turns is cancelled after START-UP the winding type of step

NOT

CANCEL - counted number of turns is not cancelled

Wire guide direction after start.


➡ -right moving the wire guide after START -UP,if its position is between left and right reversal point




⬅ - the same, but left moving

6.3.4 Wire guide shift


Coordinate of shift






Speed of the shift

The speed of shift is set at 100 mm/sek automatically, while programming.
If lower speed is required, we can change it as follows:.




Type of cycle



6.3.5 Wire guide jump

Length of jump



Direction of jump

Step : 3
Prog.: NEW

JUMP


LAYER

Length : 10.0

Cycle :



Type of cycle



Step : 3
Prog.: NEW


PROGRAMMING
END
CYCLE

STOP

ContSLOW

ContFAST

Enter type of cycle !



Step : 3
Prog.: NEW

JUMP

LAYER


Length : 10.0

Cycle :



6.3.6 Delay

Time of delay



Step : 4
Prog.: NEW

PROGRAMMING
WINDING

SHIFT


JUMP


0.00

Range : 0.00 - 99990.0 [turn]

Enter number of turns !

DELAY





Step : 4
Prog.: NEW

PROGRAMMING
DELAY

SHIFT

1200.0

WINDING

Range : 1 - 99990 [msec]

Enter time of delay !

DELAY



ENTER

Step : 4
Prog.: NEW

DELAY

LAYER

Delay : 1200

Cycle :

Type of cycle



Step : 4
Prog.: NEW

PROGRAMMING
CYCLE
END

STOP

ContSLOW

ContFAST

Enter type of cycle !



ENTER

Step : 4
Prog.: NEW

DELAY


LAYER

Delay : 1200


Cycle :

6.4 Display and assignment of the layer

We can display the number of layer instead of program. Readout showed on display can be switched by multifunction button.



We can assign the layer number to every step, according to winding instruction. The same number of layer can be assigned to a few consecutive steps. While winding, the assignment is displayed as it is programmed.



Step :	2	WINDING		LAYER
Layer :	1			
Turns .	1500.0			
L.Rev :	10.0	R.Rev :	150.0	CANCEL
Speed :	2499 :	5	Acc / Dec :	23
Pitch :	0.300			
Cycle :		Shield:	CLOSE	

6.5 Programming corrections

Following functions simplify programming or corrections.

6.5.1 Empty step insertion

Empty step can be insert anywhere inside the program and then can be completed with required parameters. Following steps are shifted in value " +1", automatically.


→

Step :	2	WIRE GUIDE RELATIVE POSITION		NEXT (1)
Prog. :	NEW			
5.0				
Range : 1.0 - 300.0 [mm]		GLOBAL CHANGE		
Setup relative position !		COPY STEP		

Step :	2	WIRE GUIDE RELATIVE POSITION		NEXT (2)
Prog. :	NEW			
5.0				
Range : 1.0 - 300.0 [mm]		INSERT STEP		
Setup relative position !		DELETE STEP		


Position for step insertion is chosen by buttons - +

Step :	2	BLOCK corr. INSERT STEP		YES
Prog.:	NEW			
<div style="border: 1px solid black; padding: 5px; margin: 10px auto; width: 100px;">INSERT</div> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="border: 1px solid black; padding: 5px; text-align: center;">2 WINDING</div> <div style="font-size: 2em;">→</div> <div style="border: 1px solid black; padding: 5px; text-align: center;">3 JUMP</div> </div>				
Insert empty step - press "YES" !				





6.5.2 Delete step

Each step in program can be deleted. Following steps are shifted in value "-1", automatically.




Step, which we wish to delete is chosen by buttons






6.5.3 Copy step

Each step, already programmed, can be copied to another step (previous or next).




Actual step is copied and inserted to the step, which is chosen by buttons - +



6.5.4 Global change


This function allows you to change one chosen parameter in all the following steps, which must be the same type. For example: if the actual step is winding, chosen parameter will be changed in all following winding steps. This is valid for all other step types (SHIFT, JUMP, DELAY).



The pitch is changed in all other consecutive winding steps.

6.5.5 Coordinate offset

Correction provides offset all coordinates in program to the left or right about entered value.




All programmed coordinates / left, right reversal points and shifts/ are incremented about value 20.0 mm.

6.6 Special functions

6.6.1 Layer stop

This function activates winding step STOP, after each wound layer.




Until programmed number of turns is not reached, machine will stop after each layer on the left or right reversal point.


If the assigned layer is displayed, this function will increment its value automatically, after each layer.





6.6.2 Automatic correction

Utilization of this function is mainly related to previous function LAYER STOP. It allows you to correct wire guide position after following start of the layer.



After the first layer is wound (e.g. from left to the right), press the wire guide correction button and correct the wire guide position. This corrected position is saved by pressing **SAVE AS RIGHT CORRECTION** button. Likewise, we insert and save the left correction after the second layer (from right to the left) is wound. For all the following layers in this step, all the corrections are done automatically, after start.








Maximal value for wire guide correction can not overreach ± 10 mm position diversion, after the layer is wound. Higher values are not accepted !

6.6.3 Automatic switch to manual regime

Function provides automatically machine switch to manual regime, after the layer or whole winding step is completed.

We can wind, just by foot pedal in manual regime. Also, the value of the pitch is taken from the actual step. The wire guide direction is controlled by multifunction button WIRE GUIDE DIRECTION. The number of turns, that is wound in this regime is not defined.




Manual regime switch OFF is done by simultaneous pressing  and  buttons.

6.6.4 Trapezoidal winding

Function provides shifting of reversal points after each layer automatically.






Switch function off

Available form of trapezoidal windings :


	left trapezoid : OFF	right trapezoid : / X,X
	left trapezoid : OFF	right trapezoid : \ X,X
	left trapezoid : \ X,X	right trapezoid : OFF
	left trapezoid : / X,X	right trapezoid : OFF
	left trapezoid : \ X,X	right trapezoid : / X,X
	left trapezoid : / X,X	right trapezoid : \ X,X
	left trapezoid : \ X,X	right trapezoid : \ X,X
	left trapezoid : / X,X	right trapezoid : / X,X

6.7 Auxiliary inputs and outputs


Machine provides an opportunity to program and control up to 4 auxiliary digital outputs and 4 digital inputs. Digital inputs and outputs are galvanise isolated. Relay is applied in standard equipment.



6.7.1 View window for inputs and outputs




6.7.2 Digital inputs programming



Each digital input can be programmed as:


- NA** - input is inactive
- I** - winding cycle interruption is done, if input is high (+ 12 V)
- S** - winding cycle start is done, if input is high (+12 V)
- SB** - start is blocked, while duration of high (+ 12V)





6.7.3 Digital outputs 1 - 4





3 following parameters can be programmed in digital outputs 1 - 4:

- level of output, after step start - up (L - relay on, H - relay off)
- level of output, after step finish - up (L - relay on, H - relay off)
- delay of output action







Delay



6.8. Program name


Created winding program should be named for quick and easy orientation. The name can consist of max.24 characters in accordance with Character scheme. If winding programs are stored to USB flash drive as well, is highly recommended to use format **8.3** (1 to 8 characters, optionally followed by a period "." then extension up to 3 characters.) For example "ern-test.tpc"








7. Program saving and opening


Actual program is placed in working part of memory. This program can be saved to an optional block or other saved program can be opened.




7.1 Program opening



Listing by button - or +






7.2 Program saving




Capacity of the internal memory is 15000 steps divided to 160 blocks. Max. step capacity is limited as follows:

Blocks 1 - 10 : max.capacity up to 350 steps
 Blocks 11 - 20, 81 - 100 : max.capacity up to 100 steps
 Blocks 21 - 80, 101 - 160 : max.capacity up to 50 steps





Select block for saving




Correct program name
if required



8. MENU

Displays and allows to change some machine basic setting.



The diagram illustrates the sequence of screens in the MACHINEsetup MENU. A hand is shown pressing the MENU button on a control panel, which leads to the first screen. The subsequent screens are shown in a vertical sequence, each with its own set of settings and options.

Screen 1: MACHINEsetup MENU (NEXT (1))

Step :	2	MACHINEsetup MENU	NEXT (1)
Prog.:	12		
Model :	ERN - 32	PROGRAM LOCK	
Number:	3		
Version :	055.816.442		
Licence :	1115		
Gear :	6000 [rpm]		
Max. width :	300.0 [mm]	USB Disc	
Programming :	UNLOCK		

Program locking

USB flash drive

Screen 2: MACHINEsetup MENU (NEXT (2))

Step :	2	MACHINEsetup MENU	NEXT (2)
Prog.:	12		
Model :	ERN - 32	MODEL	
Number:	3		
Version :	055.816.442		
Licence :	1115		
Gear :	6000 [rpm]		
Max. width :	300.0 [mm]	LANGUAGE	
Programming :	UNLOCK		

Machine model choice

Display language

Screen 3: MACHINEsetup MENU (NEXT (3))

Step :	2	MACHINEsetup MENU	NEXT (3)
Prog.:	12		
Model :	ERN - 32	JOYST.UP MODE 1	
Number:	3		
Version :	055.816.442		
Licence :	1115		
Gear :	6000 [rpm]		
Max. width :	300.0 [mm]	JOYST.DOWN MODE1	
Programming :	UNLOCK		

Joystick action

Joystick action

Screen 4: MACHINEsetup MENU (NEXT (4))

Step :	2	MACHINEsetup MENU	NEXT (4)
Prog.:	12		
Model :	ERN - 32	DELETE PROGRAM	
Number:	3		
Version :	055.816.442		
Licence :	1115		
Gear :	6000 [rpm]		
Max. width :	300.0 [mm]	CHANGE PIN CODE	
Programming :	UNLOCK		

Program (block) delete

Access code setting

Step :	2	MACHINEsetup MENU	NEXT (5)
Prog.:	12		
Model :	ERN - 32		
Number:	3		
Version :	055.816.442		SHOW LAYER
Licence :	1115		
Gear :	6000 [rpm]		
Max. width :	300.0 [mm]		ERROR MESSAGES
Programming : UNLOCK			



Display program or layer



Error messages

Step :	2	MACHINEsetup MENU	NEXT (6)
Prog.:	12		
Model :	ERN - 32		
Number:	3		MACHINE NUMBER
Version :	055.816.442		
Licence :	1115		
Gear :	6000 [rpm]		
Max. width :	300.0 [mm]		
Programming : UNLOCK			COPY NAME YES



Winder number



Accept file name

Step :	2	MACHINEsetup MENU	NEXT (7)
Prog.:	12		
Model :	ERN - 32		
Number:	3		FACTORY SETTINGS
Version :	055.816.442		
Licence :	1115		
Gear :	6000 [rpm]		
Max. width :	300.0 [mm]		
Programming : UNLOCK			



Factory settings


8.1 Program locking

Programming can be locked or unlocked by entering MASTER or PIN code. Corrections which are performed during winding process (wire guide correction, back winding, abort step e.t.c.) are not blocked.

8.2 USB flash drive


Entry to USB flash drive directory. If a USB flash drive is not connected, the button is inactive.

8.3 Machine model choice




8.4 Display language

Allows you to choose display language.




8.5 Joystick action

If the winder is equipped with four-way joystick, the action of its UP and DOWN position can be programmed. Left and right position is fixed for wire guide correction.



8.6 Program (block) delete

Working part of memory and corresponding block can be deleted.




8.7 Access PIN code setting

Available codes for user :

- MASTER code - allows you to change all settings in menu. This code is fixed by producer and is referred to guarantee certificate.
- PIN code - lock and unlock programming. This code can be set by user in range 0 - 999999
Default : "0"


8.8 Error messages

Digital control by CAN- bus provides to store and display eventual errors of Servo Drive. Displayed errors are dedicated for service.



8.9 Winder number

Winder number can be set for easy network identification.




8.10 Accept file name

Winding programs, stored as files on USB flash drive or PC, can be named in different, for example short form, as the previous.


COPY NAME
YES

- file name is accepted and displayed as a name of coil.



COPY NAME
NO

- file name is not displayed as a name of coil.



9. ERROR report

Mistakes in program are displayed by writing ERROR messages:

ERROR Microswitch

Mechanical displace of the wire guide. It appears in case, that the lateral power on the wire guide overcomes the torque of the step motor.

Next procedure: press RESET

ERROR Protection shield is open

Next procedure: press ENTER and close the shield

ERROR Spindle speed versus pitch

Pitch or spindle speed is too high (exceed the max.wire guide speed 75 mm/sek)

Next procedure: press ENTER and correct either spindle speed or pitch

ERROR Wire guide position out of range

Winding width is out of range.

Next procedure: press ENTER and correct either relative position or reversal points

ERROR Program is not logic

Program is not logic in the case type of cycle ContFAST, next step can not be the shift, jump or winding with the opposite speed direction.

10.USB host port

The controller is equipped with USB host port. This port is designed only for a USB flash drive. Do not connect any other equipments (mouse,keyboard,etc) to this port!



The suitable USB flash drive is delivered with each new machine. Mostly of another USB flash drives (KINGTON,PQI,SANDISK) can be used. We recommend to test optimal model-especially as for writing speed.

There are limitation to the type of disk which can be used. All disk must have a sector size of 512bytes various cluster size have been tested up to 32kB. Formatting FAT 16 or FAT 32

Key features


- provides reading from or writing to a USB flash drive
- tree directory for a quick program searching
- storage of unlimited winding programs
- easy transfer winding programs to or from a PC.
No other communication program needed
and no problem with cables and correct port setting
- simply and easy way for machine upgrade.
Files for upgrade can be sent by e-mail
- back-up of all winding programs in machine memory

If a flash drive is connected to the USB port, then the root directory of the flash drive is displayed.



Press to return to the winding window


→





You can disconnect the flash drive when no file is read or written.

Warning ! : If a flash drive is removed during a write operation then data corruption is likely


10.1 Display help





Press **1** to display help



Press **ENTER** to return to the root directory



10.2 Tree type structure



Press **+** or **-** to change list of directory

Max. number of displayed files or subdirectories in one directory is 100






Filename format consists of 1 to 8 characters, optionally followed by a period (".") then and extension of up to 3 characters. (8.3) For example " ern-test.tpc "




Except letters and numbers one of the following characters can be used : - _ & Space is not allowed !

IMPORTANT : Long file names are not supported .


**Note : Uppercase - name of directory
Lowercase - name of file**


10.3 Load from flash drive






10.4 Save actual program to flash drive








Enter name !
Edit text use number keys !




Enter name !
Edit text use number keys !




You can change or modify the name and extension .




Enter name !
Edit text use number keys !



10.5 Create a new directory




Enter name !
Edit text use number keys !





IMPORTANT : Long file names are not supported !

10.6 Delete file or directory








10.7 Rename file or directory







10.8 Save marked programs to USB flash drive









Required file mark by using key "C"







10.9 Save programs 1- 80 (81-160) to USB flash drive



The same procedure for programs 81-160 by key 6

10.10 Load program from USB flash drive



Note : Files will be saved in the machine's memory according to the suffix order (001-160).

Files not marked 001-160 on the flash drive will not be transferred.

10.11 Firmware upgrades



Upgrade files sent by E-mail provide upgrading the firmware if required.

There are two type of Upgrade files :


- tpccrxxx.tpc - Upgrade for the control board
- tpcdpxxx.tpc - Upgrade for the display and key board


where : xxx is version number (for example tpccr442.tpc)

Important : Consult each upgrade and especially suitable combination of versions with manufacturer.




Control board upgrade





Enter your MASTER CODE




ENTER



Wait for ENTER





Note : Upgrade tpccrxxx.tpc takes approx.one minute





check version


Diplay board upgrade




Enter your MASTER CODE




Wait for switch OFF/ ON



Between switch OFF and ON please wait a few seconds.



Note :Upgrade tpcdpxxx.tpc takes approx. two minutes



check version

11. Gear change

Timing belt drive is under the cover (15).
The machine is delivered with the default "middle" gear.

Changing the gear:

- switch OFF the machine and unplug it
- remove the cover (15), attached by 3 screws
- loosen 4 screws (17) and remove the timing belt

Changing to the gear "low"

- remove the "middle" timing gear and replace it with the "low" gear.
- use the longer timing belt, put on, tension and attach it with the screws (17)

Changing to the gear "high"


- remove both timing gears. Put the gear with the arm flange on the spindle shaft and gear "high" on the motor shaft.
- Put on the shorter narrower timing belt, tension and attach it with the screws (17).

After each gear change it is necessary to rewrite the new gear to the controller (**page 6, chapter 5.1**).

12. Serial interface RS 232

The machine is equipped with the optically isolated serial interface RS 232 for communication with PC. Connecting cable and software, offered by producer as optional accessories, allows to create and file winding program in PC.

Connector scheme



Pin	Signal
1	
2	S in
3	S out
4	
5	GND
6	
7	
8	
9	12V DC/100mA

13. PACKAGE CONTENTS

Documents delivered with the machine:

1 pc certificate of quality and completeness

1 pc user's guide

Supplied Accessories :

	ERN 22G	ERN 32G	ERN 32SG	ERN 42,52G
2 pcs fuse	T 630mA/250V	T 630mA/250V	T 630mA/250V	T 630mA/250V
2 pcs fuse	T 6,3A/250V	T 6,3A/250V		
1 pc timing gear	25 teeth	100 teeth	100 teeth	100 teeth
1 pc timing gear	64 teeth	32 teeth	32 teeth	32 teeth
1 pc timing belt	XL 160	046 019	PGGT-5MR-650-25	PGGT -5MR-650-25
1 pc timing belt	XL 210	042 012	PGGT-5MR-500-25	PGGT-5MR-500-25
allen key	4 pcs	4 pcs	4 pcs	4 pcs
2 pcs spanner	No 19, 24	No 27, 32	No 27, 32	No 36,41

14. FUSE CHANGE

Change the wrong fuses at the power switch OFF and the main power plug disconnected.
The fuses are on the back panel of the drive box. Be sure to use only the types of fuses specified by the producer.

15. MAINTENANCE

As the machine contains a minimum number of mechanical gears, the maintenance is simple.
To ensure trouble-free work, following operations are recommended:

- clean regularly the winding space of dust, dirt and wire ends
- check tension of the timing belt
- the ball bearings have permanent grease filling, no lubrication is needed

16. WARRANTY PERIOD AND SERVICE

Warranty period is 24 months from the date of delivery.
Warranty and after warranty repairs are provided by the producer.