




SPARE PARTS ERN 100T




- 12. Spindle
- 12a. Ball bearing
- 12b. Ball bearing
- 12c. Timing gear
- 13. Brake
- 23. Connector
- 24. Timing gear
- 24a. Ball bearing
- 24b. Timing gear
- 30. Emergency stop
- 31. Stand - by switch
- 32. Joystick
- 33. Start - button
- 36. Timing belt
- 37. Stop - button
- 38. Manual - button
- 39. Opto sensor

- TA 025 52
- 7210 B
- 6206 A2Z
- 80 8M 50
- BFK 458 24V/55W
- TA 048 68
- 32 8M 50 - 6F
- 6206 A2Z
- 60 5M 25 - 6W
- TA 048 71
- TA 048 76
- TA 048 74
- TA 026 41
- PGGT 8MR - 880 - 50
- TA 026 42
- TA 026 43
- QMT42VN6FF1000



SPARE PARTS ERN 100T




10. AC servo amplifier	SERVOSTAR S 712-F2	20. AC servo amplifier	TGA-24-9/20
11. Servomotor	TGT 5-1350-30-560/TOP	22. Connector	TA 048 70
12. Spindle	TA 025 52	24d. Timing gear	30 5M 25 - 6F
12c. Timing gear	80 8M 50	25. A.C.circuit braker	LPN 16C-3
14. Wire guide unit	NB SGL35A- cart	26. Relay	RSI-25-40-A230
	NB 00133 932-guide	27. Back-up power supply	UPS SMART SUA 750I
14a. Servo motor	TGT3-0250-45-320/TOP	29. Relé	RP 700 PC/230V3P
14b. Gear box	SG 090 025T3		
14c. Timing gear	T10-0-Z16		
14d. Microswitch	WN 559 00		
14e. Timing belt	PU32 T10		
14f. Ball bearing	6001 AZR		
14g. Limit switch	XCKN2121G11		
	TA 026 44		
15. Connector for pedal	TK 000 56-01		
16. Power supply unit	TK 000 36/ST 106		
17a. Power supply unit	TK 000 59/ST 107		
17b. Power supply unit	SI-HA 125000		
19. Fuse case			




SPARE PARTS ERN 100T

Gear 600 rpm



Gear 300 rpm




- 24b. Timing gear
- 24c. Timing gear
- 24d. Timing gear
- 34. Timing belt
- 35. Timing belt
- 36. Timing belt

- 60 5M 25 - 6W
- 120 5M 25 - 6W
- 30 5M 25 - 6F
- PGGT 5MR - 600 - 25
- PGGT 5MR - 800 - 25
- PGGT 8MR - 880 - 50



SPARE PARTS ERN 100T



- | | |
|-----------------|-------------------|
| 1. PCB | TK 000 - 80 - 003 |
| 2. Backplane | TK 000 73 - 00 |
| 3. Mains filter | ETI 39.19.160 |