





SPARE PARTS ERN 42 SG



- | | | |
|------|--|-----------|
| 7. | Joystick | TA 048 76 |
| 24. | Brake switch | TA 048 75 |
| 25. | Emergency stop | TA 048 71 |
| 26. | Stand - by switch | TA 048 73 |
| 27. | Stop - button | TA 026 42 |
| 28. | Start - button | TA 026 41 |
| 29. | Protection shield | TF 001 09 |
| 29a. | Shield | TA 021 64 |
| 29b. | Spring | No 14 |
| 29c. | Magnetic switch | TA 048 77 |
| 30. | Spindle collet chuck \varnothing 18 mm | TA 013 24 |
| 31. | Nut | TA 011 77 |




SPARE PARTS ERN 42 SG



- | | |
|--------------------------------|---|
| 10. AC servo amplifier | SERVOSTAR 346 |
| 11. Servomotor | TGH -5-1350-20-569/T1P |
| 12. Spindle | TA 021 25 |
| 12a. Ball bearing | S6207 CTA ABC7 DUL 85N |
| 12b. Ball bearing | 6204 P66 |
| 13. Brake | Lenze 24V21W d=20H7 |
| 14. Wire guide unit | TF 001 33 |
| 14a. Step motor | Vexta PK2913-E4.0b |
| 14b. Timing belt | 20T5-263 teeth/20mm |
| 14c. Textile band | 2x20x1400 |
| 14d. Microswitch | WN 559 00 |
| 14e. Ball bearing | 6002 AZR |
| 14f. Ball bearing | 6001 AZR |
| 15. Connector for foot - pedal | TA 026 44 |
| 17. Mains transformer | ST 01/03 |
| 19. Fuse case | SI-HA 125000 |
| 20. Stepper motor driver | TK 000 30 |
| 20a. Connector | BLA4, BLA6, BLA8, BLA14,
SLA4, SLA6, SLA8, SLA14 |
| 22. Connector | TA 022 95 |
| 23. Connector | TA 021 95 |
| 32. Relay | RSI-25-40-A230 |
| 33. A. C. circuit breaker | LPN-6C-3 |
| 34. Connector | TA 048 66 |



SPARE PARTS ERN 42 SG




- 37. Timing gear
- 38. Timing gear
- 39. Timing gear
- 40. Timing belt
- 41. Timing belt

- 30-5MR-25 / 30 teeth /
- 75-5MR-25 / 75 teeth /
- 48-5MR-25 / 48 teeth /
- 5MR-600-25 / 120 teeth / 25mm /
- 5MR-650-25 / 130 teeth / 25mm /



SPARE PARTS ERN 42 SG



- | | |
|--------------------------------|----------------------|
| 1. PCB 1. | TK 000 50 - 02 |
| 2. PCB with keyboard | TK 000 60 - 01 |
| 3. Backplane | TK 000 51 - 04 |
| 3a. Mains transformer | TRZ 007/ST 39 - 01 |
| 3b. Fuse for bluetooth adapter | 160mA/250V |
| 4. Display | PLANAR EL.240.128.45 |
| 6. Mains filter | ETI 39.19.160 |
| 7. Connector cable - display | TA 032 00 |
| 8. Connector cable -RS 232 | TA 032 01 |